



GRAPHICS CARD INSTALLATION




01
Power OFF the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).


GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).



02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.



03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.


MORE
YOU NEED TO KNOW ➤



ZOTAC.COM

CONNECT A MONITOR

CONNECTING A DISPLAY TO THE GRAPHICS CARD



USEFUL LINKS

PRODUCT REGISTRATION

Register your new product on ZOTAC.COM to get FREE extended product warranty where applicable.

Product registration must be successfully submitted within a limited time of new product purchase.


Availability and window of time for product registration may vary by product and region.

FIRESTORM UTILITY

Our advanced fine-tuning software utilizes a simplified design to allow easy and immersive control of your ZOTAC and ZOTAC GAMING graphics card. Monitor GPU performance, adjust the speed of clock, memory and fan, customize fan profile as well as SPECTRA RGB lighting, and do much more.

SUPPORT/CONTACT US

Need any help with your ZOTAC products? Please go to our Support page to find the answers, or simply contact us so we can provide the needed support.



WARRANTY

ZOTAC TECHNOLOGY LIMITED STANDS BY THE QUALITY OF ITS PRODUCTS WITH A LIMITED WARRANTY. The ZOTAC warranty ensures all products are free of material and workmanship defects from the factory. The warranty applies to the original purchaser and is non-transferable.

THE ZOTAC WARRANTY

The ZOTAC warranty is only applicable under the following conditions:

- A copy of the original sales receipt is kept.
- Damage to the product was not due to user installation.
- User did not damage the product, including abuse, overclocking, natural disaster, negligence, misuse, modifications (cooling included), power supply, damage due to the result of other damaged components, etc.
- Product was used for its intended purpose.

It is up to the original purchaser to obtain warranty service. To submit a ZOTAC graphics card for warranty service, the owner must contact the regional ZOTAC Customer Service where available or the original reseller within the standard warranty period.

NOTE!

ZOTAC TECHNOLOGY LTD. RESERVES THE RIGHT TO VOID THE WARRANTY IF:

- The product is physically modified, unless otherwise stated.
- If user purchased the card second hand.
- If user fails to produce a copy of the original sales receipt.
- User used the product in a way it was not intended for.

FAILURE TO FOLLOW THE WARRANTY TERMS AND CONDITIONS WILL RESULT IN AN AUTOMATIC VOID OF THE ZOTAC WARRANTY.

THE WARRANTY DOES NOT COVER NORMAL WEAR AND TEAR ITEMS SUCH AS THE COOLING FAN.

UNDER NO CIRCUMSTANCES IS ZOTAC TECHNOLOGY LTD. HELD LIABLE FOR ANY LOST WAGES OR REVENUES INCURRED DUE TO DEFECTIVE OR DAMAGED PRODUCTS.

ZOTAC TECHNOLOGY LTD. DOES NOT PROVIDE ANY ADDITIONAL WARRANTY FOR ITS PRODUCTS EXCEPT AS STATED IN THE WARRANTY TERMS, WHETHER BY IMPLICATION OR MERCHANT APPLICABILITY.

SAFETY

1) BEFORE PLAYING VIDEO GAMES

Make sure that the room is well illuminated and lighting is adjusted to the brightness of the monitor. Keep a suitable distance from the display monitor.

2) STATIC ELECTRICITY PRECAUTIONS

Do not touch the graphics card from the original static electricity protection package until you are ready to install it. Before installing, wear a grounded wrist strap if possible, or discharge static electricity by touching the bare metal surface of the system chassis. Carefully hold the graphics card by its rear bracket, and avoid touching the "gold finger" PCB edge connector unless necessary.

3) TURN OFF SYSTEM POWER BEFORE INSTALLING THE GRAPHICS CARD

Turn off the AC main power to the system, by the AC main power switch or by detaching the AC power cord. Damage to the graphics card or the system components, or injury to you may result if power is turned on during the installation. Please consult a qualified technician if necessary. The manufacturer assumes no liability for any damage, caused directly or indirectly, by improper installation by unauthorized service personnel.

4) ELECTRICAL SAFETY

Each graphics card requires a power supply that meets or exceeds a minimum wattage and/or PCIe connectors. High-end graphics cards may feature higher power consumption. Make sure that separate power cables are used on high power draw graphics cards and your power supply is set to the correct voltage for your region.

5) OPERATION SAFETY

Do not touch the card or block the fans from running while in operation to reduce the risk of injury. Parts such as the backplate and heatsink can be hot to the touch under heavy load. Allow at least 5 minutes to pass after powering down to make sure all components have cooled down for safe handling.


6) TRIGGER WARNING: PHOTOSENSITIVE EPILEPSY

Extremely pronounced lighting effects, such as fast image changes, repetitions of simple geometric shapes, flickering light, and bright electric arcs, or oscillations in some patterns. Even persons with no previous known tendency to epilepsy may be in danger. If you or member of your family has been diagnosed as prone to epilepsy, please consult your physician before playing the video game. Parents should monitor their children carefully when they play video games. Stop playing immediately if the following symptoms are detected: nausea, vision disturbance, muscle tension or cramps, orientational problems, involuntary movements or brief loss of consciousness.

ZOTAC®


ZOTAC.COM

GEFORCE DRIVER INSTALLATION




01
Turn off the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).


GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).




02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.



03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.

GEFORCE DRIVER INSTALLATION




01
Power OFF the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).


GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).




02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.




03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.

GEFORCE DRIVER INSTALLATION




01
Turn off the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).


GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).




02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.




03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.

GEFORCE DRIVER INSTALLATION




01
Turn off the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).


GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).




02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.



03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.

GEFORCE DRIVER INSTALLATION




01
Turn off the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).


GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).




02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.




03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.

GEFORCE DRIVER INSTALLATION




01
Turn off the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).


GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).




02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.




03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.

GEFORCE DRIVER INSTALLATION




01
Turn off the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).


GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).




02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.



03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.

GEFORCE DRIVER INSTALLATION




01
Turn off the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).


GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).




02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.




03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.

GEFORCE DRIVER INSTALLATION




01
Turn off the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).

GRAPHICS CARD INSTALLATION



04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).



02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer